

LED Indicators:

The back end of the Suga Blu baton has several LED lights to indicate the baton status.

- Flashes once, point successful read. Flashes twice, duplicate point read.
- Clocking ignored, memory buffer full.
- Moisture detected - send in for service to minimise damage.
- Flashes once when battery voltage is low and needs to be recharged. Remains blue when charging until the battery is full.
- Attempting communication with server
- Unit has been trying for 20 minutes or more but is unable to speak to the server. Possible causes are:
 - No signal
 - Network is down
 - No airtime
 - Faulty SIM card

ANY RED OR YELLOW LIGHT NEED TO BE REPORTED

